

NO. OF COPIES RECEIVED	4
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

RECEIVED
 NEW MEXICO OIL CONSERVATION COMMISSION
JUL 16 1968
O. C. C.
ARTESIA, OFFICE

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Water Injection</u>		7. Unit Agreement Name
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS		8. Farm or Lease Name Lackawanna State
3. Address of Operator Box 1311, Big Spring, Texas 79720		9. Well No. 2
4. Location of Well UNIT LETTER G 2377 FEET FROM THE North LINE AND 1554 FEET FROM THE East LINE, SECTION 21 TOWNSHIP 18S RANGE 28E NMPM.		10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) 3586 Gr.		12. County Eddy

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

OH 2126-64

1. Spot 50 sk cement plug on bottom through 2: EUE tubing using 10# mud as displacement fluid.
2. Pull tubing
3. Cut 4-1/2" casing off at 1480'.
4. Spot 25 sk cement plug at 4-1/2" casing stub.
5. Pull 4-1/2" casing.
6. Pull 894' of 8-1/4" casing.
7. Spot 25 sk cement plug at 314 (bottom of 10" casing).
8. Place 5 sk cement plug at surface and set 4-1/2" pipe marker in top of 10" casing.

JCC:ft

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson J. M. Denson TITLE Asst. District Mgr. of Prod. DATE July 15, 1968

APPROVED BY W. A. Gressett TITLE Asst. District Mgr. of Prod. DATE July 22 1968

CONDITIONS OF APPROVAL, IF ANY: