

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

RECEIVED

NEW MEXICO OIL CONSERVATION COMMISSION

OCT 14 1969

O. C. C.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. - 647

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input checked="" type="checkbox"/> GAS <input type="checkbox"/> OTHER <input type="checkbox"/> WELL <input type="checkbox"/> WELL <input type="checkbox"/>	7. Unit Agreement Name -
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS /	8. Farm or Lease Name McNutt State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 4
4. Location of Well UNIT LETTER N, FEET FROM THE LINE AND FEET FROM THE LINE, SECTION 21 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) -	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approx. 11/10/69

1. Spot 50 sk cement plug on bottom (TD 2078) through 2" EUE tubing using mud laden fluid as displacing medium.
2. Spot 25 sk cement plug at ^{1520'} 1600' (Queen Sand)
3. Spot 25 sk cement plug at 657' (bottom of 8-5/8" casing)
4. Place 5 sk cement plug in top of 8-5/8" casing and set 4" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.M. Denson

TITLE Asst. District Mgr. of Prod.

DATE 10/13/69

APPROVED BY

W. P. Gressett

TITLE

DEPT. LAND

DATE

OCT 17 1969

CONDITIONS OF APPROVAL, IF ANY:

As noted above