

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>American Petrofina Company of Texas</b>	8. Farm or Lease Name <b>McNutt State</b>
3. Address of Operator <b>Box 1311, Big Spring, Texas 79720</b>	9. Well No. <b>7</b>
4. Location of Well UNIT LETTER <b>K</b> , <b>2315</b> FEET FROM THE <b>West</b> LINE AND <b>2434</b> FEET FROM THE <b>South</b> LINE, SECTION <b>21</b> TOWNSHIP <b>18S</b> RANGE <b>28E</b> NMPM.	10. Field and Pool, or Wildcat <b>Artesia</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3568</b>	12. County <b>Eddy</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start operation approximately 4-11-69

1. Set 50 sack cement plug on bottom using mud laden fluid as a displacing medium down 2" EUE tubing.
2. Pull 1966' of 7" casing.
3. Spot 25 sack cement plug at 1600' (Top of Queen Sand).
4. Pull 655' of 8-5/8" casing.
5. Spot 25 sack cement plug at 268' (Bottom of 10-3/4" casing).
6. Place 5 sack cement plug in top of 8-5/8" casing and set 4" pipe marker.

RECEIVED

APR 8 1969

O. C. C.

ARTESIA, OFFICE

JCC/js

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. G. Whitten

TITLE District Mgr. of Production

DATE April 8, 1969

APPROVED BY

W. A. Gessett

OIL AND GAS INSPECTOR

TITLE

DATE

APR 14 1969

CONDITIONS OF APPROVAL, IF ANY: