

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

RECEIVED
 NEW MEXICO OIL CONSERVATION COMMISSION
OCT 20 1969
O. C. C.
ARTEBIA, OFFICE

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS	8. Farm or Lease Name McNutt State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 1-Y
4. Location of Well UNIT LETTER M 343 FEET FROM THE West LINE AND 282 FEET FROM THE South LINE, SECTION 21 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Eddy

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
 NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approx. 10/20/69

1. Set Bridge plug over the casing perforations (2013-2026) and dump 2 sk. cement on top of plug.
2. Cut off 5-1/2" casing at 1504' and pull.
3. Spot 25 sk. cement plug at 1500' (at 5-1/2" casing stub) using mud laden fluid as displacing medium.
4. Spot 25 sk cement plug at 450' (bottom of 8-5/8" casing).
5. Place 5 sk cement plug in top of 8-5/8" casing and set 4" pipe marker.

JCC:ft

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.M. Denson J.M. Denson TITLE Asst. District Mgr. of Prod. DATE 10/17/69

APPROVED BY

W.A. Gessett

TITLE

OIL AND GAS INSPECTOR

DATE

CONDITIONS OF APPROVAL, IF ANY: