

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED
SEP 5 1969
O.C.C.
ARTESIA OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 647
7. Unit Agreement Name
8. Farm or Lease Name Lackawanna "A" State
9. Well No. 1
10. Field and Pool, or Wildcat Artesia
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Injection well
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS
3. Address of Operator Box 1311, Big Spring, Texas 79720
4. Location of Well UNIT LETTER J , 1573 FEET FROM THE South LINE AND 1573 FEET FROM THE East LINE, SECTION 21 TOWNSHIP 18-S RANGE 28-E N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) 3582 Gr.

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approx. 9-10-69

1. Spot 50 sk cement plug on bottom (TD 2163) through 2" EUE Tubing using mud laden fluid as displacing medium.
2. Cut off 4-1/2" casing at 650' and pull.
3. Spot 25 sk cement plug at 650' (^{4 1/2"} 5-1/2" casing stub.)
4. Spot 25 sk cement plug at 450' (bottom of 8-5/8" casing.)
5. Place 10 sk cement plug in top of 8-5/8" casing and set 4-1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.M. Denson J.M. Denson TITLE Asst. District Mgr. of Prod. DATE 9/4/69

APPROVED BY W.A. Gressett TITLE Oil and Gas Inspector

DATE SEP 5 1969

CONDITIONS OF APPROVAL, IF ANY: