

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/ ✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

MAY 4 1970

O. C. C.
BUREAU, OFFICE

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No 647
7. Unit Agreement Name
8. Farm or Lease Name Lackawanna "A" State
9. Well No. 4
10. Field and Pool, or Wildcat Artesia
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator AMERICAN PETROLEUM COMPANY OF TEXAS ✓
3. Address of Operator Box 1311, Big Spring, Texas 79720
4. Location of Well UNIT LETTER J 2346 FEET FROM THE South LINE AND 1500 FEET FROM THE East LINE, SECTION 21 TOWNSHIP 16S RANGE 28E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3567 Gr.

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approximately May 7, 1970.

1. Spot 50 sk cement plug on bottom through 2" EUE tubing using mud laden fluid as displacing medium.
2. Pull 6-5/8" casing (2119'). Spot 25 sk cement plug at 1500' (Queen Sand).
3. Pull 8-1/4" casing (635'). Spot 25 sk cement plug at 314' (bottom of 10" casing.)
4. Place 10 sk cement plug in top of 10" casing & set 4-1/2" pipe marker.

JCC/tx
4/28/70

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. C. Chapman J. C. Chapman TITLE Production Engineer DATE 4/28/70

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE MAY 4 1970

CONDITIONS OF APPROVAL, IF ANY: Intervals between plugs filled with mud