

NO. OF COPIES RECEIVED	4
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

**RECEIVED**  
NEW MEXICO OIL CONSERVATION COMMISSION  
JUL 16 1968

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. - 647
7. Unit Agreement Name -
8. Farm or Lease Name Lackawanna State
9. Well No. 5
10. Field and Pool, or Wildcat Artesia
12. County Eddy

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS ✓
3. Address of Operator Box 1311, Big Spring, Texas 79720
4. Location of Well UNIT LETTER <u>H</u> , <u>2382</u> FEET FROM THE <u>North</u> LINE AND <u>1069</u> FEET FROM THE <u>East</u> LINE, SECTION <u>21</u> TOWNSHIP <u>18S</u> RANGE <u>28E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3582 Gr.

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- CH 2148-90
- Spot 50 sx cement plug on bottom through 2" tubing using 10# mud as displacement fluid.
  - Cut off 4-1/2" casing at 680'.
  - Spot 25 sk cement plug at 4-1/2" casing stub.
  - Spot 25 sk cement plug at 516' (Bottom of 7" casing).
  - Pull 4-1/2" casing.
  - Spot 5 sx cement plug at surface and place 4-1/2" pipe marker in top of 7" casing.

JCC:ft

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.M. Denson J.M. Denson

TITLE Asst. District Mgr. of Prod. DATE 7-15-68

APPROVED BY

W. A. Gressett

TITLE

W. A. Gressett

DATE

7-15-68

CONDITIONS OF APPROVAL, IF ANY: