

CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED

MAY - 8 1980

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-11540
7. Unit Agreement Name
8. Farm or Lease Name Vandeventer
9. Well No. 4
10. Field and Pool, or Wildcat Artesia
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REFINER OR PLUG BACK TO A WELL OR TO REPAIR OR MAINTAIN A WELL. USE APPLICATION FOR PERMIT TO DRILL OR TO REFINER OR PLUG BACK TO A WELL OR TO REPAIR OR MAINTAIN A WELL.)

ARTESIA, OFFICE

OIL WELL <input checked="" type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER <input type="checkbox"/>
Name of Operator W. E. Jeffers		
Address of Operator P. O. Box 65, Artesia, New Mexico 88210		
Location of Well UNIT LESSER B 330 FEET FROM THE North LINE AND 1650 FEET FROM THE East LINE, SECTION 22 TOWNSHIP 18s RANGE 28e N.M.P.M.		

15. Elevation (Show whether DF, RT, GR, etc.)

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

REPAIR REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
REPAIR ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPERATIONS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
REPAIR OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Have N. L. McCullough Tool Co. Set cast iron bridge plug @ 2200' in 5 1/2" casing. Dump 35' cement on top of plug.

Then if hole is dry, fill 5 1/2" pipe with mud.

If hole is full of water-or if nearly full, finish filling with water-run free-point log, cut pipe off, fill hole with mud, inside and outside of 5 1/2" casing.

Pull 5 1/2", run 2" tubing and displace 100' of cement, 50' in and 50' over top of casing stub.

Then, depending on where casing stub is, whether we put another 100' plug at 1200'.

Put 25 sax at 650' to 750'. 35 sax at 380' to 480', and tag to check top of cement.

Install monument and marker in cement at surface. Fill pit and clean up location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

W. E. Jeffers	TITLE <u>Owner</u>	DATE <u>May 8-1980</u>
W. A. Gresset	TITLE <u>SUPERVISOR, DISTRICT II</u>	DATE <u>MAY - 9 1980</u>
CONDITIONS OF APPROVAL, IF ANY:		

Notify N.M.O.C.C. in sufficient time to witness

Plugging