

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. --

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- Water Injection	7. Unit Agreement Name --
2. Name of Operator American Petrofina Company of Texas	8. Farm or Lease Name Resler Yates State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 13
4. Location of Well UNIT LETTER B 2400 FEET FROM THE East LINE AND 250 FEET FROM THE North LINE, SECTION 28 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia
11. Elevation (Show whether DF, RT, GR, etc.) 3559 Gr.	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

OH 2070-99

Estimated start 10-16-68

- Run 2" EUE tubing to bottom and spot 50 sack cement plug using 10# mud.as displacement medium.
- Cut off 4 1/2" casing at 1250' and pull.
- Spot 25 sack cement plug at 4 1/2" casing stub.
- Spot 25 sack cement plug at 275' (bottom of 10").
- Place 5 sack cement plug at surface and set 4" pipe marker.

RECEIVED
OCT 14 1968
O. C. C.
ARTESIA, OFFICE

JCC/js

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson TITLE Asst. Dist. Mgr. of Production DATE 10-11-68

APPROVED BY W. A. Gressett TITLE STEAM GAS INSPECTION DATE 10-11-68

CONDITIONS OF APPROVAL, IF ANY: