

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator American Petrofina Company of Texas	8. Farm or Lease Name Welch Duke State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 11
4. Location of Well Footage not available UNIT LETTER F FEET FROM THE LINE AND FEET FROM NW SE NW THE LINE, SECTION 28 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) --	12. County Eddy

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approximately 1-27-68

1. Spot 50 sx cement plug on bottom through 2" tubing using mud laden fluid as displacing medium.
2. Spot 25 sx cement plug at 1570 (Top Queen Sand).
3. Pull 665' - 8-1/4" casing.
4. Spot 25 sx cement plug at 303' (Bottom of 10" casing).
5. Place 5 sx cement plug at top of 10" casing.
6. Set 4" pipe marker.

RECEIVED

JAN 13 1969

O. C. C.
ARTESIA, OFFICE

JCC/js

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. G. Whitten D. G. Whitten TITLE Dist. Mgr. of Production DATE January 9, 1969

APPROVED BY W. A. Gessett TITLE CLERK GAS DIVISION DATE JAN 13 1969

CONDITIONS OF APPROVAL, IF ANY: