

NO. OF COPIES RECEIVED	2
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
--	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection Well		7. Unit Agreement Name
2. Name of Operator American Petrofina Company of Texas		8. Farm or Lease Name Resler Yates State
3. Address of Operator Box 1311, Big Spring, Texas 79720		9. Well No. 51
4. Location of Well UNIT LETTER B 1770 FEET FROM THE East LINE AND 530 FEET FROM THE North LINE, SECTION 28 TOWNSHIP 18S RANGE 28E NMPM.		10. Field and Pool, or Wildcat Artesia
11. Elevation (Show whether DF, RT, GR, etc.)		12. County Eddy

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Star wor approximately 10-23-68

1. Run tubing to bottom and spot 50 sack cement plug using 10# mud as displacement medium.
2. Cut off 4 1/2" OD casing @ 1760'. Spot 25 sack cement plug at casing stub and Queen Sd.
3. Pull 8 5/8" casing (set at 938')
4. Spot 25 sack cement plug at 265' (bottom of 10")
5. Place 5 sack cement plug at top of 10" casing.
6. Set 4" pipe marker.

RECEIVED
OCT 15 1968
O. C. C.
ARTESIA, OFFICE

JCC/jls

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson J. M. Denson TITLE Asst. Dist. Mgr. of Production DATE 10-14-68

APPROVED BY W. A. Gressett TITLE SEAL AND ONS INSPECTOR DATE 1968

CONDITIONS OF APPROVAL, IF ANY: