

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

FEB 4 1970

O. C. C.
ARTESIAL OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No.
647

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Unit Agreement Name
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS	8. Farm or Lease Name Recker Yates State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 348
4. Location of Well UNIT LETTER N 330 FEET FROM THE South LINE AND 1650 FEET FROM THE West LINE, SECTION 29 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia
11. Elevation (Show whether DF, RT, GR, etc.) 3559 GL	12. County Eddy

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>

ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>

OTHER

OTHER

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set 25 ex cement plug over perforations in 3-1/2" casing (from 1986 - 1999) through 2" EUE tubing using mud laden fluid as displacing medium.
- * 2. Cut off 3-1/2" casing at 990' and pull. 25 sack plug here
3. Spot 25 ex cement plug at 523' (Bottom of 8-5/8" casing).
4. Place 10 ex cement plug in top of 8-5/8" casing and set 4-1/2" OD pipe marker.

JCC/ja

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson TITLE Asst. Dist. Mgr. of Production DATE February 3, 1970

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE

CONDITIONS OF APPROVAL, IF ANY: Internals between plugs filled with mud
* 25 sack plug @ 5 1/2" casing stub