

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
--

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>American Petrofina Company of Texas</b>	8. Farm or Lease Name <b>Resler Yates State</b>
3. Address of Operator <b>Box 1311, Big Spring, Texas 79720</b>	9. Well No. <b>58</b>
4. Location of Well UNIT LETTER <b>J</b> , <b>1650</b> FEET FROM THE <b>South</b> LINE AND <b>2310</b> FEET FROM THE <b>East</b> LINE, SECTION <b>29</b> TOWNSHIP <b>18S</b> RANGE <b>28E</b> NMPM.	10. Field and Pool, or Wildcat <b>Artesia</b>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County <b>Eddy</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approximately 10-25-68

1. Run 2" EUE tubing to bottom and spot 50 sack cement plug using 10# mud as displacement medium.
2. Spot 25 sack cement plug at 1550' (Queen Sd.)
3. Spot 25 sack cement plug at 454' (Bottom of 8" casing)
4. Place 5 sack cement plug at top of 8" casing.
5. Set 4" pipe marker.

JCC/js

RECEIVED  
OCT 15 1968  
G. D. G.  
ARTESIA OFFICE

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson J. M. Denson

TITLE Asst. Dist. Mgr. of Production DATE 10-14-68

APPROVED BY W. A. Gressett

TITLE NEW MEXICO DATE OCT 21 1968

CONDITIONS OF APPROVAL, IF ANY: