

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
647	
7. Unit Agreement Name	
-	
8. Farm or Lease Name	
Basler Yates State	
9. Well No.	
10	
10. Field and Pool, or Wildcat	
Artasia	
12. County	
Eddy	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator
American Petrofina Company of Texas
3. Address of Operator
Box 1311, Big Spring, Texas 79720
4. Location of Well
UNIT LETTER I , 260 FEET FROM THE East LINE AND 2380 FEET FROM THE South LINE, SECTION 29 TOWNSHIP 18S RANGE 28E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)
3560 Gr.

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JCB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pump 50 sack cement plug to bottom of hole through 2" EUE tubing using 10# mud to displace. Fill up 50'.
 2. Pull 1150' of 4 1/2" OD casing.
 3. Fill hole with 10# mud.
 4. Spot 25 sack cement plug at 1150'.
 5. Spot 25 sack cement plug at 530' (Bottom of 7" casing).
 6. Put 5 sack cement plug and 4" pipe marker in top of 7" casing. Fill up 22'.
- This work will commence on or about February 20, 1968.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Danaon TITLE Asst. Dist. Mgr. of Production DATE December 21, 1967

APPROVED BY W. A. Gressett TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: