

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

OCT 14 1969

O. C. C.
ARTESIA, OFFICE

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	-

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS /	8. Farm or Lease Name Cowell State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 11
4. Location of Well UNIT LETTER <u>K</u> <u>2399</u> FEET FROM THE <u>south</u> LINE AND <u>1560</u> FEET FROM THE <u>west</u> LINE, SECTION <u>4</u> TOWNSHIP <u>18S</u> RANGE <u>28E</u> NW PM.	10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) 3662 DF	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approximately 10/28/69

- Spot 50 sk cement plug on bottom (TD 2297) through 2" EUE tubing using mud laden fluid as displacing medium.
- Cut off 4-1/2" casing at 1590', spot 25 sk plug & pull casing. *at top of Queen approx 1420*
- Spot 25 sk cement plug at 498' (Bottom of 8" csg.)
- Place 5 sk cement plug in top of 8" casing and set 4" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.M. Denson TITLE Asst. District Mgr. of Prod. DATE 10/13/69

APPROVED BY W. A. Grissett TITLE OIL AND GAS INSPECTOR

DATE OCT 17 1969

CONDITIONS OF APPROVAL, IF ANY: as noted above