

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

RECEIVED
 NEW MEXICO OIL CONSERVATION COMMISSION
 MAY 9 1969
 O. C. C.
 ARTESIA, OFFICE

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 703 (2)	
7. Unit Agreement Name	
8. Farm or Lease Name Levers State	
9. Well No. 4	
10. Field and Pool, or Wildcat Artesia	
12. County Eddy	

SUNDRY NOTICES AND REPORTS ON WELLS
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection
2. Name of Operator American Petrofina Company of Texas
3. Address of Operator Box 1311, Big Spring, Texas 79720
4. Location of Well UNIT LETTER M 1049 FEET FROM THE South LINE AND 1065 FEET FROM THE West LINE, SECTION 4 TOWNSHIP 18S RANGE 28E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3654 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approximately 5-19-69

1. Spot 50 sk cement plug at TD 2320 through 2" EUE tubing using mud laden fluid as displacing medium.
2. Cut off 5-1/2" casing at 1600' and pull.
3. Spot 25 sk cement plug at 1600' (or 5-1/2" casing stub). *at Top of Queen **
4. Spot 25 sk cement plug at 675' (Bottom of 7" casing).
5. Cut off 7" casing at 495' and pull.
6. Spot 25 sk cement plug at 495' (or at 7" casing stub).
7. Place 10 sk cement plug at surface and set 4" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson J. M. Denson TITLE Asst. Dist. Mgr. of Production DATE May 8, 1969

APPROVED BY W. A. Grissett TITLE OIL AND GAS INSPECTOR DATE MAY 12 1969

CONDITIONS OF APPROVAL, IF ANY: *