

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

1968

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>American Petrofina Company of Texas</b>	8. Farm or Lease Name <b>Lavers State</b>
3. Address of Operator <b>Box 1311, Big Spring, Texas 79720</b>	9. Well No. <b>8</b>
4. Location of Well UNIT LETTER <b>N</b> , <b>1075</b> FEET FROM THE <b>South</b> LINE AND <b>1567</b> FEET FROM THE <b>West</b> LINE, SECTION <b>4</b> TOWNSHIP <b>18S</b> RANGE <b>28E</b> NMPM.	10. Field and Pool, or Wildcat <b>Artesia</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3643 Gr.</b>	12. County <b>Eddy</b>

16.

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

#### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

#### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Spot 50 sk. cement plug on bottom through 2" tubing using 10# mud as displacement fluid.
  2. Pull 654' of 8 1/4" casing.
  3. Spot 25 sk. cement plug at 654'.
  4. Spot 25 sk. cement plug at 245 ft. (Bottom of 10" casing).
  5. Place 5 sk. cement plug at surface and set 4 1/2" pipe marker in top of 10" casing.
- Work should start on or about August 12, 1968.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cliff Chapman **Cliff Chapman** TITLE Petroleum Engineer DATE July 26, 1968

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE AUG 1 1968

CONDITIONS OF APPROVAL, IF ANY: 2 ft. a