

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

MAY 9 1969

O. C. C.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 703(2)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection	7. Unit Agreement Name
2. Name of Operator American Petrofina Company of Texas ✓	8. Farm or Lease Name Levers State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 10
4. Location of Well UNIT LETTER N , 1061 FEET FROM THE South LINE AND 2271 FEET FROM THE West LINE, SECTION 4 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) 3660 GR	12. County Elddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approximately 5-22-69

1. Spot 50 sk cement plug at TD 2350 through 2" EUE tubing using mud laden fluid as displacing medium.
2. Cut off 4-1/2" OD casing at 1776' and pull.
3. Spot 25 sk cement plug at 1776' (or 4-1/2" casing stub). *on top of Queen X*
4. Pull 8-5/8" casing.
5. Spot 25 sk cement plug at 251' (Bottom of 10-3/4" casing).
6. Place 10 sk cement plug in top of 10-3/4" casing and set 6" pipe marker.

JCC/jc

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson J. M. Denson TITLE Asst. Dist. Mgr. of Production DATE May 8, 1969

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE MAY 12 1969

CONDITIONS OF APPROVAL, IF ANY: *