

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103 *Copy to S.F.*  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <b>Water injection well</b>		7. Unit Agreement Name
2. Name of Operator <b>American Petrofina Company of Texas</b>		8. Farm or Lease Name <b>Solt Welch State</b>
3. Address of Operator <b>Box 1311, Big Spring, Texas 79720</b>		9. Well No. <b>5</b>
4. Location of Well UNIT LETTER <b>L</b> <b>269</b> FEET FROM THE <b>West</b> LINE AND <b>1578</b> FEET FROM THE <b>South</b> LINE, SECTION <b>4</b> TOWNSHIP <b>18S</b> RANGE <b>28E</b> NMPM.		10. Field and Pool, or Wildcat <b>Artesia</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3652 GR</b>		12. County <b>Eddy</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Start work approximately 1-15-68**

1. Spot 50 sx cement plug on bottom through 2" tubing using mud laden fluid as displacing medium.
2. Cut off 4-1/2" csg at 1800 ft and pull.
3. Spot 25 sx cement plug at 1800' (4-1/2" csg stub).
4. Spot 25 sx cement plug at ~~1600'~~ (Top of Queen). 1423
5. Spot 25 sx cement plug at 300' (Bottom of 8-5/8" csg).
6. Place 5 sx cement plug in top of 8-5/8 casing.
7. Set 4" pipe marker.

**RECEIVED**

**JAN 8 1969**

**O. C. C.**

**ARTESIA, OFFICE**

JCC/js

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *D. G. Whitten* **D. G. Whitten** TITLE **Dist. Mgr. of Production** DATE **January 7, 1969**

APPROVED BY *W. A. Gressett* TITLE **OIL AND GAS INSPECTOR** DATE **JAN 10 1969**

CONDITIONS OF APPROVAL, IF ANY: *as noted above*