

NO. OF COPIES RECEIVED	2
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED

NEW MEXICO OIL CONSERVATION COMMISSION

O. C. C.  
ARTESIA, OFFICE

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
<b>7011539</b>

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
<b>American Petroleum Company of Texas</b>	<b>Humble Stout State</b>
3. Address of Operator	9. Well No.
<b>Box 1311, Big Spring, Texas 79720</b>	<b>1</b>
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER <b>I</b> , <b>330</b> FEET FROM THE <b>East</b> LINE AND <b>2310</b> FEET FROM	<b>Artasia</b>
THE <b>South</b> LINE, SECTION <b>4</b> TOWNSHIP <b>18S</b> RANGE <b>28E</b> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
<b>---</b>	<b>Eddy</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Start work approximately 6-7-71**

1. Through 7" EUE tubing spot 25 sz cement on bottom (TD 2526') using mud laden fluid as displacing medium.
2. Spot 25 sz cement plug at 1518' (Queen sand)
3. Spot 25 sz cement plug at 505' (8-5/8" csg. seat)
4. Place 10 sz cement plug in top of 8-5/8" casing and set 4" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson TITLE Asst. Dist. Mgr. of Production DATE June 2, 1971

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE JUN 8 1971

CONDITIONS OF APPROVAL, IF ANY: