

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

RECEIVED
DEC 31 1970

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
13-3823

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. CIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
AMERICAN PETROLEUM COMPANY OF TEXAS	Salt State
3. Address of Operator	9. Well No.
Box 1311, Big Spring, Texas 79720	2
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER A , 338 FEET FROM THE North LINE AND 332 FEET FROM	Artesia
THE East LINE, SECTION 5 TOWNSHIP 18S RANGE 28E NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3657 CL	Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE: RULE 1103.

Start work approximately 1-6-71

Run 2" NME tubing and spot 50 sx cement plug on bottom (TD 2336) using mud laden fluid as displacing medium.

Cut off 7" casing at 725' and pull.

Spot 25 sx cement plug at 725' (7" casing stub)(also bottom of 8-5/8" casing)

Cut off 8-5/8" casing at 370' and pull.

Spot 25 sx cement plug at 370' (8-5/8" casing stub).

Place 10 sx cement plug at surface and set 4-1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Benson TITLE Asst. Dist. Mgr. of Production DATE December 29, 1970

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE DEC 31 1970

CONDITIONS OF APPROVAL, IF ANY: Spot a 25 sack plug @ 1390