

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE\*  
(Other instructions on reverse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 046256-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Coppedge

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Loco Hills

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 5-18S-30E NMPM

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☐ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

NEWMONT OIL COMPANY

3. ADDRESS OF OPERATOR

P. O. BOX 1305, ARTESIA, NEW MEXICO 88210

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

330' FNL &amp; 1980' FWL of Sec. 5; T-18S; R-30E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☒CHANGE PLANS ☐

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

We propose to plug and abandon this well by the following procedure:

1. Set cast iron plug at 2750'.
2. Place 5 sack cement plug on top of cast iron plug.
3. Cut 7" at free point and pull.
4. Place 25 sack plug in top of 7" pipe left in hole.
5. Place 25 sack plug at bottom of 8 5/8" surface casing at 485'.
6. Pull free portion of 8 5/8" pipe.
7. Place marker at surface in 5 sacks of cement.

RECEIVED  
NOV 18 1971  
U. S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED Herbert J. LedbetterTITLE Division SuperintendentDATE 11/18/71

(This space for Federal or State office use)

APPROVED BY  
CONDITIONS OF APPROVAL, IF ANY:

APPROVED

NOV 22 1971  
R. L. BECKMAN  
ACTING DISTRICT ENGINEERIf 7" Csg is cut & pulled from  
below 1500', a 25 sack cement plug  
will be placed at base of cut  
1100 - 1200.  
Heavy mud between all plugs.

\*See Instructions on Reverse Side