

UNITED STATES DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY  
NEW MEXICO OIL AND GAS CONSERVATION DIVISION  
(Other Instructions on Reverse Side)  
Artesia, NM 88210

Form approved.  
Budget Bureau No. 42-R1424.  
5. LEASE DESIGNATION AND SERIAL NO.

LC 048468

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> WIW - <del>SA</del> TA AUG 3 1982		7. UNIT AGREEMENT NAME WEST LOCO HILLS GRB #4 SD	
2. NAME OF OPERATOR NEWMONT OIL COMPANY		8. FARM OR LEASE NAME TRACT 2B	
3. ADDRESS OF OPERATOR P. O. BOX 1305 ARTESIA, NEW MEXICO 88210		9. WELL NO. 3	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 330' FNL 2310 FEL Sec. 18-18-30		10. FIELD AND POOL, OR WILDCAT LOCO HILLS (Q. G. SA)	
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3513'	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 18-18-30	
		12. COUNTY OR PARISH Eddy	
		13. STATE New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

<input type="checkbox"/>
<input type="checkbox"/>
<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>
<input type="checkbox"/>

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Pull tubing and packer
2. Spot sufficient cement across producing interval to tie back to production string casing seat, or set bridge plug near casing seat and cap with 25 sack cement plug.
3. Perforate base of salt @ 1125' and squeeze with 50 sacks cement leaving 100' plug in casing.
4. Perforate top of salt @ 395' and squeeze with 50 sacks cement leaving 100' plug in casing.
5. Set 15 sack cement plug at surface tying surface and production casing together.
6. Erect permanent well marker

Note: (A.) Your office will be notified 24 hrs. prior to operations.  
(B.) All plugs will be verified  
(C.) Hole will be loaded between all plugs with 10# mud  
(D.) We do not plan to pull any casing.

18. I hereby certify that the foregoing is true and correct

SIGNED

*Ernest J. McLaughlin*

TITLE

Area Manager

DATE

7/23/82

(This space for Federal or State Approval)

APPROVED

APPROVED BY (Orig. Sgd.) PETER W. CHESTER  
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

JUL 30 1982

FOR

JAMES A. GILLHAM  
DISTRICT SUPERVISOR

\*See Instructions on Reverse Side