WW OTH COME TO Drawer DD Artesia, NM 88210 CIST

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals SUBMIT IN TRIPLICATE		FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993 5. Lease Designation and Serial No. LC-029418 B 6. If Indian, Alottee or Tribe Name 7. If Unit or CA, Agreement Designation		
	MIT IN TRIPLICATE	8. Well Name and Number		
1. Type of Well: OIL GAS WELL WELL	OTHER	LEA D		
2. Name of Operator TEXACO EXPLO	RATION & PRODUCTION INC.	2		
3. Address and Telephone No. P.O. BOX 730, He	OBBS, NM 88240 397-0431	9. API Well No.		
4. Location of Well (Footage, Sec., T., R., M., or	3001505412 10. Field and Pool, Exploaratory Area			
Unit Letter A : 710 Feet From	The NORTH Line and 660 Feet From The	GRAYBURG JACKSON 7RVS-QN-GB-SA		
EAST Line Section 26	Township 17S Range 31E	11. County or Parish, State EDDY , NEW MEXICO		
12. Check Appropriate	e Box(s) To Indicate Nature of Notice, R	eport, or Other Data		
TYPE OF SUBMISSION	Т	YPE OF ACTION		
Notice of Intent Subsequent Report Final Abandonment Notice	Abandonment Recompletion Plugging Back Casing Repair Atlering Casing OTHER: TEMPORARILY ABAN	Change of Plans New Construction Non-Routine Fracturing Water Shut-Off Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log Form.)		
work. If well is directionally drilled, give subsu	Clearly state all pertinent details, and give pertinent dates, in urface locations and measured and true vertical depths for a SUBJECT WELL IS FOR SALE AND THE PURCHASION OF	Il markers and zones pertinent to this work,)*.		
2. MIRU. TOH WITH PRODUCTION EQUIP		DEC 22:191		
	DST PERF), AND CAP WITH 35 FEET OF CEMENT.	0. C. 9		
	NHIBITOR FLUID. TEST CASING AND PLUG WITH	ALCEN CHAP NO		
5. CLASSIFY WELL TO TA STATUS. TEPI N REQUESTING TEMPORARILY ABANDON	WILL SUBMIT PRESSURE CHART AND SUBSEQUENT IMENT STATUS ON THIS WELL.	(1)		

14. I hereby certify that the foregoing is the and correct SIGNATURE JITLE	Engineering Assistant	DATE	6/29/94
TYPE OR PRINT NAME Darrell J Carriger			
(This space for Federal (ORIG: SGD.) JOE G. LARA APPROVED BY	PETROLEUM ENGINEER	DATE 12	119/94
conditions of APPROVAL, IF ANY: See attached	Test to be performed	L within	90 days

BUREAU OF LAND MANAGEMENT CARLSBAD RESOURCE AREA

Temporary Abandonment of Wells on Federal Lands

Conditions of Approval

According to 43 CFR 3162.3-4-c, "No well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer".

Temporary Abandonment (TA) status approval requires a successful casing integrity test as follows:

- 1. Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Eddy County call (505) 887-6544; for wells in Lea County call (505) 393-3612.
- A bridge plug or packer shall be set at a maximum of 50 feet above any open perforations or open hole.
- 3. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.
- 4. The production casing shall be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes with a 10% allowable leak-off.

Wells that successfully pass the casing integrity test will be approved for Temporary Abandonment (TA) status for 12 months provided that the operator:

- 1. Submits a subsequent Sundry Notice requesting TA approval,
- 2. Attaches a clear copy or the original of the pressure test chart,
- 3. And attaches a detailed justification why the well should not be plugged and abandoned.

The TA status could be extended without another casing integrity test provided there was no leak-off during the test.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

- 1. A procedure to repair the casing so that a TA approval can be granted.
- 2. A procedure to plug and abandon the well.