

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

MAY 10 1970

OFFICE OF THE
ARTESIAN ENGINEER

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No 647
7. Unit Agreement Name -
8. Farm or Lease Name Resler Yates State
9. Well No. 383
10. Field and Pool, or Wildcat Artesia
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
2. Name of Operator American Petrofina Company of Texas
3. Address of Operator Box 1311, Big Spring, Texas 79720
4. Location of Well UNIT LETTER G , 2310 FEET FROM THE North LINE AND 1850 FEET FROM THE east LINE, SECTION 28 TOWNSHIP 18S RANGE 28E N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) 3548 Gr.

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approximately 5/21/70

1. Spot 25 sk cement plug over casing perforations 2052-2072, through 2" EUE tubing using mud laden fluid as displacing medium.
2. Cut off 5-1/2" casing at 1522 and spot 25 sk cement plug. (Top of Queen.
3. Pull 5-1/2" casing.
4. Spot 25 sk cement plug at 556' (Bottom of 8-5/8" casing).
5. Place 10 sk cement plug in top of 8-5/8" casing and set 4" pipe marker.

JCC:ft
5/11/70

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cliff Chapman **Cliff Chapman** TITLE Production Engineer DATE May 11, 1970

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE MAY 11 1970

CONDITIONS OF APPROVAL, IF ANY: Is the cement plug placed within mud