

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection Well		7. Unit Agreement Name
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS		8. Farm or Lease Name Resler Yates State
3. Address of Operator Box 1311, Big Spring, Texas 79720		9. Well No. 14
4. Location of Well UNIT LETTER G 2390 FEET FROM THE North LINE AND 2388 FEET FROM THE East LINE, SECTION 28 TOWNSHIP 18S RANGE 28E NMPM.		10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) Gr. 3531		12. County Eddy

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approx. 10-21-68

- Run 2" EUE tubing to bottom and spot 25 sk cement over casing perforations from 2023-44 using 10# mud as displacement medium.
- Cut off 5-1/2" csg at 1000'.
- Spot 25 sx cement plug at 5-1/2" casing stub.
- Pull 8-5/8" casing (1000')
- Spot 25 sx cement plug at 260' (Bottom of 10-3/4" casing)
- Place 5 sx cement plug in top of 10-3/4" casing
- Set 4" pipe marker.

JCC:ft

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.M. Denson TITLE Asst. District Mgr. of Prod. DATE Oct. 11, 1968

APPROVED BY W.A. Gressett TITLE Oil and Gas Inspector DATE Oct 11 1968

CONDITIONS OF APPROVAL, IF ANY: