

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED NEW MEXICO OIL CONSERVATION COMMISSION

MAY 3 1971

O. C. C.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-7866

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Sun Oil Company	8. Farm or Lease Name South Hope Unit
3. Address of Operator P. O.Box 1861 Midland, Texas 79760	9. Well No. 2
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>810</u> FEET FROM THE <u>East</u> LINE, SECTION <u>36</u> TOWNSHIP <u>18 S</u> RANGE <u>21 E</u> NMPM.	10. Field and Pool, or Wildcat South Hope Penn.
15. Elevation (Show whether DF, RT, GR, etc.) 4132 DF	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging operations to begin approximately 5-20-71 as follows:

1. Load hole with 9.5# mud.
2. Squeeze 25 sacks cement below packer set @ 7250. (Perfs 7277-7297).
3. Locate free point, shoot and pull 4 1/2" casing.
4. Spot 100 ft. plug in and out of casing stub.
5. Spot plugs 3400-3500, 1742-1842, 550-650, 10 sacks at surface; set marker.
6. Clear location and level all pits.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>RW Hughes</u>	TITLE <u>Proration Clerk</u>	DATE <u>4-30-71</u>
APPROVED BY <u>W. A. Gressett</u>	TITLE <u>OIL AND GAS INSPECTOR</u>	DATE <u>MAY 3 1971</u>
CONDITIONS OF APPROVAL, IF ANY: <u>Plugging operations</u>		

Notify N.M.O.C.C. in sufficient time to witness