

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87500

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED

DEC 08 '87

<p><b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</p>		<p>5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/></p>
<p>5. State Oil &amp; Gas Lease No. B-4109</p>		<p>7. Unit Agreement Name</p>
<p>6. Name of Operator J. Pete Thompson</p>		<p>8. Farm or Lease Name Maljamar St.</p>
<p>Address of Operator 403 2nd Place Abernathy, Texas 79311</p>		<p>9. Well No. 2</p>
<p>Location of Well UNIT LETTER <u>A</u>, <u>330</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM THE <u>East</u> LINE, SECTION <u>36</u> TOWNSHIP <u>17S</u> RANGE <u>31 E</u> NMPM.</p>		<p>10. Field and Pool, or Wildcat Maljamar</p>
<p>15. Elevation (Show whether DF, RT, GR, etc.) 3859 GR</p>		<p>12. County Eddy</p>

<p>16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data</p>			
<p>NOTICE OF INTENTION TO:</p>		<p>SUBSEQUENT REPORT OF:</p>	
<p>PERFORM REMEDIAL WORK <input type="checkbox"/></p>	<p>PLUG AND ABANDON <input checked="" type="checkbox"/></p>	<p>REMEDIAL WORK <input type="checkbox"/></p>	<p>ALTERING CASING <input type="checkbox"/></p>
<p>TEMPORARILY ABANDON <input type="checkbox"/></p>	<p>CHANGE PLANS <input type="checkbox"/></p>	<p>COMMENCE DRILLING OPS. <input type="checkbox"/></p>	<p>PLUG AND ABANDONMENT <input type="checkbox"/></p>
<p>PULL OR ALTER CASING <input type="checkbox"/></p>	<p>OTHER <input type="checkbox"/></p>	<p>CASING TEST AND CEMENT JOB <input type="checkbox"/></p>	<p>OTHER <input type="checkbox"/></p>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

- (1) Set CIBP @ 3900 + w/35' Cmt Cap
- (2) Load hole w/mud
- (3) Find TOC behind 4½
- (4) Cut & pull Csg @ + \_\_\_\_\_
- (5) Spot 35 Sx Cmt inside & outside stub & Tag
- (6) Spot 25 Sx @ 3240' - Top Queen - 3192'
- (7) Spot 25 Sx @ 2170' - Base Salt TX 990 BX 2120
- (8) Spot 35 Sx @ 1100 & tag - Shoe 8 5/8
- (9) Surface plug (60') 10 to 15 SX

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. Pete Thompson TITLE OWNER DATE Dec. 3, 1987

APPROVED BY Mike Williams TITLE OIL AND GAS INSPECTOR DATE DEC 10 1987

CONDITIONS OF APPROVAL, IF ANY: