

CIBP @ 1475'

Authorized Plug on  
top of CIBP then  
continue w/ Plug Procedure

---

Berry/Berry  
59-021

State of New Mexico  
Energy, Minerals and Natural Resources Department

OIL CONSERVATION DIVISION

P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

DISTRICT I  
P.O. Box 1980, Hobbs NM 88240  
DISTRICT II  
P.O. Drawer DD, Artesia NM 88210  
DISTRICT III  
1000 Rio Brazos Rd., Aztec NM 87410

WELL APPL NO.  
**30-015-10886**

5. Indicate Type of Lease  
State ☐ FEE ☒

7. Lease Name or Unit Agreement Name  
**Gerard AW**

8. Well No  
**#2**

9. Pool Name or Wildcat  
**Penasco Draw San Andres Yeso**

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL ☐ GAS ☐  
WELL ☒ WELL ☐ OTHER ☐

2. Name of Operator  
**Yates Petroleum Corporation**

3. Address of Operator  
**105 South 4th., Artesia, NM 88210**

4. Well Location  
Unit Letter **J** : **2310** Feet From The **South** Line and **1650** Feet From The **East** Line  
Section **25** Township **18S** Range **25E** NMPM **Eddy** COUNTY

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
**3455' GR**

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <input type="checkbox"/>		OTHER <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to intent to plug and abandon:

NOTE: A NOTICE OF INTENTION TO SET CIBP AT 1275' WAS SUBMITTED TO THE OCD IN 1998 NO RECORD OF THE WORK CAN BE FOUND.

1. Make gauge ring run to CIBP @ 1500'. Dump 35' cement on plug. Set CIBP @ 1275'.  
Dump 35' cement on plug.

2. MIRU a WSU. ND wellhead. TIH w/tubing to and tag cement on CIBP @ 1240'. Circulate hole with mud. Pull up and spot 100' cement plug 1115' to 1015'. — TA?

3. Perforate circulating hole at 100' and circulate cement around between 8 5/8" and 5 1/2" to surface. Set marker as per Rule 202.2.2

Notify OCD in Artesia with 24 hour notice before commencing operation (505) 748-1283

Salt gel mud consisting of 10#  
Brine W/25# of gel per bbl  
must be placed between each plug

1475' CIBP  
2 DAYS DRILLING Produced no  
RESULTS.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Erma Vazquez TITLE Operations Technician DATE 1/10/02

TYPE OR PRINT NAME Erma Vazquez TELEPHONE NO 505-748-1471

(This space for State Use)

APPROVED BY [Signature] TITLE Field Rep DATE JAN 25 2002

CONDITIONS OF APPROVAL, IF ANY