

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED
 NEW MEXICO OIL CONSERVATION COMMISSION
OCT 14 1980
O. C. D.
 ARTESIA, OFFICE

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. NM 647

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- WATER INJECTION WELL	7. Unit Agreement Name
2. Name of Operator BOYD OPERATING COMPANY	8. Farm or Lease Name Rotary State
3. Address of Operator P. O. Box 1756, Roswell, New Mexico 88201	9. Well No. 7
4. Location of Well UNIT LETTER J 2650 FEET FROM THE W LINE AND 2650 FEET FROM THE N LINE, SECTION 20 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or Wildcat Art. Qn, Gb. S.A.
15. Elevation (Show whether DF, RT, GR, etc.) 3589 G.L.	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
 NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

8 5/8" @ 520'; 4 1/2" @ 2500'; Top perforations @ 1996'-2008.

1. Squeeze perforations through retainer.
2. Cut off 4 1/2" at + or - 1350'. Spot 35 sack plug over stub.
3. Spot 35 sack plug @ 900'-1000' (7 Rivers).
4. Spot 35 sack plug over surface casing shoe (450'-550')
5. Feel plug.
6. Spot 10 sack plug and marker at surface.
7. Clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><i>L. M. Boyd</i></u>	TITLE <u>Operator</u>	DATE <u>10/10/80</u>
APPROVED BY <u><i>W. A. Gressett</i></u>	TITLE <u>SUPERVISOR, DISTRICT II</u>	DATE <u>OCT 16 1980</u>
CONDITIONS OF APPROVAL, IF ANY:	Notify N.M.O.C.C. in sufficient time <u>Plugging</u>	