

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

# OIL CONSERVATION DIVISION

P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. <b>30-015-22034</b>
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

RECEIVED

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Lease Name or Unit Agreement Name  Gulf HI
2. Name of Operator YATES PETROLEUM CORPORATION	8. Well No. 1
3. Address of Operator 105 South 4th St., Artesia, NM 88210	9. Pool name or Wildcat Atoka San Andres
4. Well Location Unit Letter <u>J</u> : <u>1650</u> Feet From The <u>South</u> Line and <u>1750</u> Feet From The <u>East</u> Line Section <u>28</u> Township <u>18S</u> Range <u>26E</u> NMFM <u>Eddy</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3374' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows:

- Set CIBP at 1550'. Cap with 35' of cement.
- Stretch, cut and pull 4-1/2" and 5-1/2" casing.
- GIH w/tubing and load hole with salt gel mud.
- Spot 125' plug across tub. NOTE: If longstring is not pulled from below 1184', will also spot plug across from 1250' up to ~~900'~~ <sup>850'</sup> (7" shoe at 1184' and San Andres top at 989').
- Set 25 sack surface plug. Install regulation abandonment marker.

NOTE: NOTIFY NMOC (748-1283) 24 HOURS PRIOR TO COMMENCING OPERATIONS.

Notify N.M.A.C.C. in sufficient time to witness

\* Plug 506 - 606

Plugging

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE June 17, 1993  
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY [Signature] TITLE OIL AND GAS INSPECTOR DATE 7/14/93  
CONDITIONS OF APPROVAL, IF ANY: