

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-79

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED BY

NOV -3 1986

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT TO DRILL" FORM C-101 FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> GAS <input type="checkbox"/> OTHER- P&A	7. Unit Agreement Name
2. Name of Operator Yates Petroleum Corporation	8. Farm or Lease Name Midwest HH Com
3. Address of Operator 105 South 4th St., Artesia, NM 88210	9. Well No. 1
4. Location of Well UNIT LETTER F, 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 21 TOWNSHIP 18S RANGE 27E NMPM.	10. Field and Pool, or Whdcat Undesignated Strawn
15. Elevation (Show whether DF, RT, GR, etc.) 3345' GR	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Propose to plug well as follows:
Set CIBP at 8450' w/35' cement on top.
Shoot off 4½" casing at about 7700', circulate hole with mud, lay down casing.
Set cement plugs as follows:
35 sx 50' in and 50' out of stub
35 sx at 6440-6340'
35 sx at 4350-4250'
35 sx at 3250-3150'
35 sx at 1675-1575' (across 8-5/8" shoe)
25 sx at 300-200' (across 13-3/8" shoe)
10 sx at surface with dry hole marker.

Verbal permission obtained for plugging from Mr. Les Clements, NMOCD, Artesia by Mr. Eddie Mahfood, YPC.

Witnessed by C.C. in sufficient time to witness

Plugging

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Francisco Lopez* TITLE Production Supervisor DATE 10-31-86

APPROVED BY *Mike Williams* TITLE OIL AND GAS INSPECTOR DATE NOV 06 1986

CONDITIONS OF APPROVAL, IF ANY: