

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

30-015-23496

5. Indicate Type of Lease

STATE ☐

FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name

Rio Penasco OJ Com

8. Well No.

1

9. Pool name or Wildcat

Undesignated Atoka

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☐

GAS
WELL ☒

OTHER

2. Name of Operator

YATES PETROLEUM CORPORATION

3. Address of Operator

105 South Fourth Street - Artesia, NM 88210

4. Well Location

Unit Letter J : 1980 Feet From The South Line and 1980 Feet From The East Line

Section

34

Township

18S

Range

25E

NMPM

Eddy

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3485' GR

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: Abandon Wolfcamp & recomplete to Atoka ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to abandon Wolfcamp and recomplete to the Atoka as follows:

1. TOOH with rods and pump. Nipple down tree and nipple up and test BOP. TOOH with tubing.
2. Set RBP at 5800'± and cap with sand. Pressure test RBP. Set cement retainer at 5650'±. Squeeze Wolfcamp perforations at 5680'. WOC.
3. Drill out retainer and cement. Pressure test perforations to ensure squeeze is holding. TOOH with RBP at 5800'. Ensure wellbore is clear.
4. TIH w/casing gun and perforate 8585-890' w/21 holes (4 SPF - Feb 23, 1995)
5. TIH w/packer to 8550'± and acidize perforations.
6. Swab and test.

RECEIVED

FEB 23 1995
OIL CON. DIV.
DIST. 2

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Rusty Klein

TITLE

Production Clerk

DATE 2-22-95

TYPE OR PRINT NAME

Rusty Klein

505-748-1471
TELEPHONE NO.

(This space for State Use)

ORIGINAL FILED BY THE STATE
OIL CONSERVATION DIVISION

FEB 27 1995

TITLE

DATE