	1 .	•		Form C-103	
DISTRIBUTION			RECEIVED BY	Supersedes Old	
SANT A FE	V	NEW MEXICO C	IL CONSERVATION COMMISSION	C-102 and C-103 Effective 1-1-65	
FILE	VV		MAR 21 1985	20000000 1-1-03	
U.S.G.S.				5a. Indicate Type of Lease	
LAND OFFICE		1	O. C. D.	State X Fee	, \square
OPERATOR			ARTESIA, OFFICE	5, State Oil & Gas Lease No.	
				V-409	
	SUNDRY N	OTICES AND REPOR	ETS ON WELLS		777
(DO NOT USE THIS FO USE	AM FOR PROPOSA	OR PERMIT -" (FORM C-101	RTS.ON WELLS OR PLUG BACK TO A DIFFERENT RESERVE) FOR SUCH PROPOSALS.)	JR. (////
I.				7. Unit Agreement Name	7777
WELL X WELL	<u> </u>	OTHER-	-		
2. Name of Operator				8. Farm or Lease Name	
SANTA RITA EXPLO 3. Address of Operator	ORATION CO	ORPORATION		Phoenix State	
		00010		9. Well No.	
P. O. Box 798, A	Artesia, N	N. M. 88210		#1	
	220	NT.	000	- 10. Field and Pool, or Wildcat	
UNIT LETTERD		FEET FROM THE	orth 1990	FEET FROM Und. Maljamar GB-SA	A
	_				////
THE West	INE, SECTION3	36 TOWNSHIP _	175	NMPM.	/////
	mm	15 Flevation (Show	whether DF, RT, GR, etc.)		<i>HH</i> ,
		3827 GR	whether Dr, RI, GR, etc.)	12. County	////
16.	Charle Ass			Eddy //////	7777,
NOTIC	Check Appr CE OF INTEN	opriate Box To Indi	cate Nature of Notice, Repo		
140110	E OF INTER	1110N 10:	SUB.	SEQUENT REPORT OF:	
PERFORM REMEDIAL WORK	1	PLUG AND ABAND	🗖	<u></u>	
TEMPORARILY ABANDON	ាំ	PLUG AND ABAND		ALTERING CASING	님
PULL OR ALTER CASING	ĺ	CHANGE PLANS	COMMENCE DRILLING OPNS.	PLUG AND ABANDONMEN	ʻT 📙
	•		OTHER		
OTHER					
7 Describe Proposed on Co.		(C)			
work) SEE RULE 1 103.	"breted Obergitio	ms (Clearly state all perti	nent details, and give pertinent dates	, including estimated date of starting any pro	posed
Casing: 750' 24	¥# 85/8 €	emented w/150 sk	s "C" and 350 sks "lit	e"	
Circula	ated 120 s	ks.			
			$^\prime$ 450 sks "C" and 1000 s	ks "lite"	
Circula	ated 90 sk	S.			
D . C	,010 51	1 0000 0000			
Perforations: 4			22 1 5- 5 (010	F1	
	'C' at 225		2 and peris from 4016-	51 squeezed with 200 sks	
1	C at 223	Oir •			
,					
	ıl: Circu	late hole w/mud.			
Plugging Proposa				top of CIBP.	
	Set C	SIBP at 3820 and	spot 30' of cement on	top of CIBP.	
Plugging Proposa	Set C 25 sk	IBP at 3820 and s from 3280-3040	spot 30' of cement on (Queen)	top of CIBP.	
Plugging Proposa	Set C 25 sk 25 sk	SIBP at 3820 and	spot 30' of cement on (Queen) (B. salt)	top of CIBP.	
Plugging Proposa	Set C 25 sk 25 sk 25 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610'	spot 30' of cement on (Queen) (B. salt)		
Plugging Proposa	Set C 25 sk 25 sk 25 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610'	spot 30' of cement on (Queen) (B. salt) (shoe)	installed.	
Plugging Proposa	Set C 25 sk 25 sk 25 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610'	spot 30' of cement on (Queen) (B. salt) (shoe)		
Plugging Proposa	Set C 25 sk 25 sk 25 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610'	spot 30' of cement on (Queen) (B. salt) (shoe)	installed.	
Plugging Proposa	Set C 25 sk 25 sk 25 sk 10 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610's surface plug a	spot 30' of cement on (Queen) (B. salt) (shoe) and appropriate marker	installed.	
Plugging Proposa	Set C 25 sk 25 sk 25 sk 10 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610's surface plug a	spot 30' of cement on (Queen) (B. salt) (shoe)	installed.	
Plugging Proposa	Set C 25 sk 25 sk 25 sk 10 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610's surface plug a	spot 30' of cement on (Queen) (B. salt) (shoe) and appropriate marker	installed.	
Plugging Proposa	Set C 25 sk 25 sk 25 sk 10 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610's surface plug a	spot 30' of cement on (Queen) (B. salt) (shoe) and appropriate marker	installed.	
Plugging Proposa	Set C 25 sk 25 sk 25 sk 10 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610's surface plug a	spot 30' of cement on (Queen) (B. salt) (shoe) and appropriate marker	installed.	
Plugging Proposa	Set C 25 sk 25 sk 25 sk 10 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610's surface plug a	spot 30' of cement on (Queen) (B. salt) (shoe) and appropriate marker	installed.	
Plugging Proposa	Set C 25 sk 25 sk 25 sk 10 sk	TIBP at 3820 and s from 3280-3040 s from 2090-1840 s from 850'-610's surface plug a	spot 30' of cement on (Queen) (B. salt) (shoe) and appropriate marker	installed.	<u></u>

NO. OF COPIES RECEIVED