

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
310 Old Santa Fe Trail, Room 206  
Santa Fe, New Mexico 87503

WELL API NO. 30-015- <del>1897</del> 25250
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E - 9261
7. Lease Name or Unit Agreement Name Midstream "16" State Com.
8. Well No. 1
9. Pool name or Wildcat Illinois Camp North
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3617' GR

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Mewbourne Oil Company	
3. Address of Operator P.O. Box 5270 Hobbs, New Mexico 88241	
4. Well Location Unit Letter <u>L</u> : <u>2310</u> Feet From The <u>South</u> Line and <u>990</u> Feet From The <u>West</u> Line Section <u>16</u> Township <u>18S</u> Range <u>28E</u> NMPM Eddy County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3617' GR	

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRU PU. Set CIBP @ 6475' and cap with 35' cement. Load hole with 25#/bbl. brine and salt gel. Spot 25 sx. plug @ 4400'. Attempt 5-1/2" casing cut off @ 3100'. Spot a 100' plug across casing stub and tag cement. Spot 25 sx. plug @ 2780' and tag. Spot 25 sx. plugs @ 1000' and 460'. Set 10 sx. surface plug. Set dry hole marker, cut anchors and clean location. Will notify OCD 24 hours before starting.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Gregory Milner TITLE Engineer DATE 3/30/95  
TYPE OR PRINT NAME Gregory Milner TELEPHONE NO. (505) 393-5905

(This space for State Use)

**ORIGINAL SIGNED BY RAY SMITH**

APPROVED BY Field Rep II TITLE Field Rep II DATE 3/30/95  
CONDITIONS OF APPROVAL, IF ANY: