

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

NM CONS COMMISSION  
Drawer DD  
Artesia, NM 88210

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

5. Lease Designation and Serial No.  
**NM 56542**

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No. **CULWIN 35**  
**FEDERAL # 1**

9. API Well No.  
**30-015-3570700**

10. Field and Pool, or Exploratory Area  
**SHUGART Y, SR, Q, G**

11. County or Parish, State  
**EDDY CO. NM**

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

**MERIDIAN OIL INC.**

3. Address and Telephone No.

**P.O. Box 51810 Midland, TX 79710**

**915-688-6943**

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

**1855' FSL & 635' FEL**

**SEC. 35, T18S, R30E**

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☒ Other **DRILL OUT CIBP**  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. MIRU. ND WH. NU BOP. POOH W/RODS AND PMP. POOH W/TBG.
2. MIRU REVERSE UNIT. RIH W/BIT FOR 4 1/2" CSG. CLEAN OUT FILL TO CIBP AT 3100. DRILL UP CIBP AT 3100. CONTINUE CLEANING OUT WELLBORE TO CIBP @ 3345 (USE 2% KCL WATER FOR DRILLING). POOH. RDMO REVERSE UNIT.
3. RIH W/PRODUCTION TBG.  
SET SN @ +\ -2232'. ND BOP. NU WH.
4. RIH W/RODS AND PMP. PUT WELL ON PRODUCTION.

REQUEST FOR VERBAL APPROVAL. PLAN ON MOVING ON LOCATION 2/25/94.



14. I hereby certify that the foregoing is true and correct

Signed

**DONNA WILLIAMS**

Title **PRODUCTION ASSISTANT**

Date **2/24/94**

(This space for Federal or State office use)

Approved by

**(OPIG. SGD.) JOE G. LARA**

Title

**PETROLEUM ENGINEER**

Date

**3/8/94**

Conditions of approval, if any: