

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
310 Old Santa Fe Trail, Room 206  
Santa Fe, New Mexico 87503

WELL API NO. 30-015-27009
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E - 1286
7. Lease Name or Unit Agreement Name Turkey Track "15" State
8. Well No. 1
9. Pool name or Wildcat Wildcat - Bone Spring
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3597' GR

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Meybourne Oil Company
3. Address of Operator P.O. Box 5270 Hobbs, New Mexico 88241	4. Well Location Unit Letter E : 1980 Feet From The North Line and 990 Feet From The West Line Section 15 Township 18S Range 28E NMPM Eddy County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3597' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRU PU. GIH & tag CIBP @ 7897'. Cap if not capped with cement. Set a 100' plug across DVT @ 7776'. Set CIBP @ 6318' and cap with 35' cement. Load hole with 25#/bbl. salt gel and brine. Spot 25 sx. plugs @ 3655', 2678', 1702', 600' and 390'. Set a 10 sx. surface plug. Set dry hole marker, cut anchors, and clean local hole. Will notify OCD 24 hours before starting.

RECEIVED  
MAR 29 1995  
OIL CON. DIV.  
DIST. 2

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Gregory Milner TITLE Engineer DATE 3/28/95  
TYPE OR PRINT NAME Gregory Milner TELEPHONE NO. (505) 393-5905

(This space for State Use)

APPROVED BY Ray Smith TITLE OIL CON. DIV. SUPERVISOR DATE 3-29-95  
CONDITIONS OF APPROVAL, IF ANY.