

Submit 3 Copies To Appropriate District Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
811 South First, Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

Form C-103  
Revised March 25, 1999

WELL API NO. **30-015-29458**

5. Indicate Type of Lease  
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.  
B-11276

7. Lease Name or Unit Agreement Name:  
TRAVIS ATR 24 STATE COM

8. Well No.  
#1

9. Pool name or Wildcat  
PALMILLO DRAW ATOKA

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR TO PLUG BACK OR TO ABANDON A WELL IN A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
Oil Well ☐ Gas Well ☒ Other ☐

2. Name of Operator  
Harvey E. Yates Company

3. Address of Operator  
P.O. Box 1933, Roswell, New Mexico 88202

4. Well Location  
Unit Letter K : 1980 feet from the SOUTH line and 1980 feet from the WEST line  
Section 24 Township 18S Range 28E NMPM EDDY County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

WE INTEND TO PLUG AND ABANDON THE WELL AS FOLLOWS:

1. SET CIBP @ <sup>10,100'</sup> ~~10,000'~~ + 35' CEMENT.
2. CIRCULATE 9# MUD.
3. CUT & PULL APPX 8900' 5 1/2" CSG, SPOT 100' CLASS 'H' CMT PLUG FROM 8,950'-8,850'. TAG PLUG.
4. SPOT 150' CLASS 'C' CMT PLUG FROM 6,000'-5,850'.
5. SET 100' CMT PLUG FROM 3,175'-3,075'. 100' Plug 750'-850'
6. SPOT 100' CMT PLUG FROM 450'-350'. TAG PLUG.
7. SET 20 SX CMT SURFACE PLUG. INSTALL DRY HOLE MARKER.

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jeanette Atkinson TITLE Production Analyst DATE 10/9/02

Type or print name Jeanette Atkinson Telephone No. 505-623-6601  
(This space for State use)

APPROVED BY [Signature] TITLE Field Rep ID DATE OCT 25 2002  
Conditions of approval, if any: