			rom approveu.		
Form 3160-5	UNITD STATES	SUBMIT IN TRIPLICTE.	Budget Bureau No. 1004-0135 Expires August 31, 1985		
(November 1983) (Formerly 9-331)	DEPARTMEN JF THE IN	TERIOR verse stdel	5. LEASE DESIGNATION AND BERIAL NO		
(Formerry 9+331)	BUREAU OF LAND MANAG		LC-062376		
		THE COLLECTION OF THE D	6. IF INDIAN, ALLOTTEE OR TRIBE NAME		
SUNI	DRY NOTICES AND REPO	RTS ON WELES			
(Do not use this l	form for proposals to drill or to deepen o Use "APPLICATION FOR PERMIT-" fo	or plug back to a different reservoir. or such proposals.)	-		
1.			7. UNIT AGREEMENT NAME		
OIL GAS	OTHER	HAR IJ 9 ûf AM 189	-		
2. NAME OF OPERATOR		CARLO	8. FARM OR LEASE NAME		
Yates Drilling Company		AREA HILL STRE	Lane Federal		
3. ADDRESS OF OPERATOR			8. WELL NO.		
	th Street, Artesia, N.M.	88210	4		
4. LOCATION OF WELL (R	eport location clearly and in accordance w	10. FIELD AND POOL, OR WILDCAT			
See also space 17 belo At surface	w .)	NL CLIVED	Red Hills Yates		
			11. SEC., T., B., M., OE BLE. AND SURVEY OR AREA		
990' FSL &	0001 551	MAR 16 '89			
990° FSL &	990 FEL	MAR TO 03	Sec.29-19S-30E		
14. PERMIT NO.	15. ELEVATIONS (Show w	bether DF, RT, GR, etc.)	12. COUNTY OF PARISH 13. STATE		
	3282	O. C. D.	Eddy N.M.		
		ARTESIA, OFFICE	Where Data		
16.	Check Appropriate Box to Ind	icate Nature of Notice, Report, or C			
N	NOTICE OF INTENTION TO :	SUBSEQU	BUBSEQUENT REPORT OF:		
TEST WATER SHUT-OF	PULL OR ALTER CASING	WATER SHUT-OFF	REPAIRING WELL		
PRACTUBE TREAT	MULTIPLE COMPLETE	FRACTURE TREATMENT	ALTERING CASING		
SHOUT OR ACIDIZE	ABANDON*	SHOOTING OR ACIDIZING	ABANDON MENT [®]		
REPAIR WELL	CHANGE PLANS	(Other)			
(Other)		(Norr: Report results Completion or Recompl	of multiple completion on Well letion Report and Log form.)		
17. DESCRIBE PROPOSED OR proposed work. If nent to this work.)	well is directionally drilled, give subsuri	pertinent details, and give pertinent dates, ace locations and measured and true vertice	including estimated date of starting any il depths for all markers and zones perti-		
1. Rig	up pulling unit and TOH	with rods and tubing.			
2. TIH	with wireline and set CI	BP at approx. 1570'.	mou the half an		
		ant to fill (1/2" casing			

- TIH with tubing and pump cement to fill 4 1/2" casing, TOH with tubin and top off casing with cement. Total cement 110 sacks class "C".
 Wait and allow cement to settle, add additional cement if necessary. ıg
- Erect 5' X 4" marker marked with well information. 5.
- 6. Clean and level location.

18. I hereby certify that the foregoing is true and correct SIGNED	TITLE	Engineer	DATE	3-8-89
(This space for Federal or State office use) APPROVED BY CONDITIONS OF APPROVAL, IF ANY:	TITLE		DATE	3-15-89

*See Instructions on Reverse Side