

UNITED STATES M. O. C. DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY

Form approved. Budget Bureau No. 42-R1424. 5. LEASE DESIGNATION AND SERIAL NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

LC 047633 (a) 6. IF INDIAN, ALLOTTEE OR TRIBE NAME 7. UNIT AGREEMENT NAME 8. FARM OR LEASE NAME D.M. Swearingen "A" 9. WELL NO. 10. FIELD AND POOL, OR WILDCAT Shugart 11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 14, T-18S, R-31E 12. COUNTY OR PARISH Eddy 13. STATE N.M.

1. OIL WELL [X] GAS WELL [] OTHER [] 2. NAME OF OPERATOR Atlantic Richfield Company 3. ADDRESS OF OPERATOR P. O. Box 1978, Roswell, New Mexico 88201 4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FSL & 660' FEL (Unit Letter I) 14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3722 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: TEST WATER SHUT-OFF [] FRACTURE TREAT [] SHOOT OR ACIDIZE [] REPAIR WELL [] (Other) [] FULL OR ALTER CASING [] MULTIPLE COMPLETE [] ABANDON* [X] CHANGE PLANS [] SUBSEQUENT REPORT OF: WATER SHUT-OFF [] FRACTURE TREATMENT [] SHOOTING OR ACIDIZING [] (Other) [] REPAIRING WELL [] ALTERING CASING [] ABANDONMENT* [] (NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Production on this well had declined to 1/2 BOPD + 99% water. The well was shut in during August, 1969. We now propose to P & A as follows:

- 1. Set 30 sack cement plug from 3510-3380'.
2. Shoot off and recover 7" casing as deep as possible
3. Set these cement plugs:
30 sx in and out of 7" stub.
30 sx across 8-5/8" shoe, @ 950'.
10 sx in top of well.

Salt gel mud will be used to spot all plugs. 8-5/8" casing string will remain intact. A dry hole marker will be installed and location cleared & levelled.

RECEIVED JUN-3 1970

RECEIVED

U.S.G. ARTESIA, OFFICE

18. I hereby certify that the foregoing is true and correct SIGNED [Signature] TITLE Dist. Drlg. Supervisor DATE 6-1-70

APPROVED BY CONDITIONS OF APPROVAL, IF ANY: TITLE DATE

APPROVED [Signature] H. L. BEEKM