

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
BLM - CARLSBAD

CONTACT RECEIVING
OFFICE FOR NND
OF COPIES REQUIRED
(Other instructions on re-
verse side)

BLM Roswell District
Modified Form No.
NND60-3160-4

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	2. NAME OF OPERATOR Marbob Energy Corporation	3a. Area Code & Phone No. 505-748-3303	5. LEASE DESIGNATION AND SERIAL NO. NM 06813
3. ADDRESS OF OPERATOR P. O. Drawer 217, Artesia, NM 88210	4. LOCATION OF WELL (Report location clearly and in accordance with any State requirement. See also space 17 below.) At surface 990 FSL 1980 FEL		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.)	7. UNIT AGREEMENT NAME
16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data		8. FARM OR LEASE NAME Tidewater FE	
NOTICE OF INTENTION TO:		9. WELL NO. 1	
TEST WATER SHUT-OFF ☐ PULL OR ALTER CASING ☐ WATER SHUT-OFF ☐ REPAIRING WELL ☐		10. FIELD AND POOL, OR WILDCAT Hackberry Yates SR-North	
FRACTURE TREAT ☐ MULTIPLE COMPLETION ☐ FRACTURE TREATMENT ☐ ALTERING CASING ☐		11. SEC., T., R., M., OR BLK. AND SURVEY OR ARMA Sec. 19-T19S-R31E	
SHOOT OR ACIDIZE ☐ ABANDON* ☒ SHOOTING OR ACIDIZING ☐ ABANDONMENT* ☐		12. COUNTY OR PARISH Eddy	
REPAIR WELL ☐ CHANGE PLANS ☐ (Other) ☐		13. STATE NM	

RECEIVED

JUL 17 1992

O. C. D.
ARTESIA OFFICE

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

We propose to plug and abandon as follows:
NOTIFY BLM AT (505) 887-6544 PRIOR TO ANY WORK.
Set cmt plug from 2140' to 1934'. Tag plug @ 1934'. Set cmt plug from 1830' to 1730'. (Base Salt). Perf csg @ 630' and circ cmt to surface inside and out 4 1/2" csg. If in the event we cannot circ cmt to surface, we will squeeze perfs @ 630' w/ 50 sx cmt and tag cmt @ 580'. Set surface plug and install dry hole marker and clean location. 50'

Fill WELL BORE (BETWEEN PLUGS) WITH 9 ppg MUD.
USE CLASS "C" CEMENT MIXED WITH 6.3 GALS. OF FRESH WATER PER SACK.

RECEIVED

JUL 17 1992

18. I hereby certify that the foregoing is true and correct

SIGNED Robin Smith TITLE Production Clerk DATE 7/8/92

(This space for Federal or State office use)

APPROVED BY Adam Selamoff TITLE _____ DATE 7/15/92

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side