AS COMMISSION NM OIL

Form 3160-5 (June 1990)

1. Type of Well Oil Well

2. Name of Operator

3. Address and Telephone No.

Other

Devon Energy Corporation (Nevada)

20 N. Broadway, Suite 100, OKC, OK 73102-8260

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

1 tm -		
Drawer	DD	1
	NM	88210

RECEIVED

405/295-00622

FORM APPROVED

-	Bureau No.	
Exp	ires: March	31, 1993
Lease Desi	gnation and	Senal No.

SUNDRY NOTICE	S AND REP	ORTS ON	WELLS
---------------	-----------	---------	-------

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

	5. Lease Designation and Senal No.		
	NM10190		
	6. If Indian, Allottee or Tribe Name		
Ì	7. If Unit or CA, Agreement Designation		

East Shugart Unit #32

10. Field and Pool, or Exploratory Area

14-08-001-11572

8. Well Name and No.

30-015-20254

9. API Well No.

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)			Shugart (Y-SR-Q-G)
100	' FSL & 990' FWL, Sec. 3	-T18S-R31E, Unit M	11. County or Purish, Since Eddy, NM
12.	CHECK APPROPRIATE BOX	(s) TO INDICATE NATURE OF	NOTICE, REPORT, OR OTHER DATA
TYPE OF SUBMISSION			TYPE OF ACTION
	Notice of Intent	Abandçament	Change of Plans
	Subsequent Report	Recompletion Plugging Back	New Construction Non-Routine Fracturing
	Final Abandonment Notice	Caning Repair Altering Casing	Water Shut-Off Conversion to Injection
13. Describe I	Proposed or Completed Operations (Clearly state	X Other run inte	(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) g continuous date of starting any proposed work. If well is dispersionable deliberation

(1) Rig up pump truck on casing.

Load casing with water and pressure test to 500 psi for 30 mins (2)

The BLM will be notified 24 hours prior to testing.

14. I hereby certify that the foregoing is the and correct Signed Candace R. France	Title _	Candace R. Graham Engineering Tech.	Date	06-15-94
(This space for Federal or State office use)				
Approved by Salameh Conditions of approval, if any:	Title _	Potroleum Engineer	Date	7/20/94
A A C 1 1 5				

ATTA CHED ~

Title 18 U.S.C. Section 1001, makes it a cris vingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent s or representations as to any matter with

BUREAU OF LAND MANAGEMENT CARLSBAD RESOURCE AREA

Temporary Abandonment of Wells on Federal Lands

Conditions of Approval

According to 43 CFR 3162.3-4-c, " No well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer".

Temporary Abandonment (TA) status approval requires a successful casing integrity test as follows:

- Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Eddy County call (505) 887-6544; for wells in Lea County call (505) 393-3612.
- 2. A bridge plug or packer shall be set at a maximum of 50 feet above any open perforations or open hole.
- 3. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.
- 4. The production casing shall be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes with a 10% allowable leak-off.

Wells that successfully pass the casing integrity test will be approved for Temporary Abandonment (TA) status for 12 months provided that the operator:

- Submits a subsequent Sundry Notice requesting TA approval,
- 2. Attaches a clear copy or the original of the pressure test chart,
- 3. And attaches a detailed justification why the well should not be plugged and abandoned.

The TA status could be extended without another casing integrity test provided there was no leak-off during the test.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

- A procedure to repair the casing so that a TA approval can be granted.
- 2. A procedure to plug and abandon the well.

. 4.4