

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

2040 Pacheco St.
Santa Fe, NM 87505

WELL API NO. 30-015-25876	
Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>	
State Oil & Gas Lease No.	
Lease Name or Unit Agreement Name Glass 7E	
Well No. 1	
Pool name or Wildcat Four Mile Draw, Morrow, West (Gas)	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	
Name of Operator Nearburg Producing Company	
Address of Operator 3300 N A St., Bldg 2, Suite 120, Midland, TX 79705	
Well Location Unit Letter <u>E</u> : <u>1980</u> Feet From The <u>FNL</u> Line and <u>660</u> Feet From The <u>FWL</u> Line Section <u>7</u> Township <u>19S</u> Range <u>26E</u> NMPM <u>Eddy</u> County	
Elevation (Show whether DF, RKB, RT, GR, etc.)	

11

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
 TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
 PULL OR ALTER CASING ☐
 OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
 COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
 CASING TEST AND CEMENT JOB ☐
 OTHER: ☐

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Nearburg Producing Company request to plug and abandon the above referenced well.

1. Set CIBP @ 9200'. Cap w/ 35' cmt.
2. Set 25 sx plug @ 8940'.
3. Set 25 sx plug @ 6293'.
4. Set 25 sx plug @ 3200'.
5. Set 25 sx plug @ 1416'. (8-5/8" @ 1366') - TAG
6. Set 25 sx plug @ 417'. (13-3/8" @ 367') - TAG
7. Set 60' surface plug and install dry hole marker

**Salt gel mud consisting of 10#
Brine W/25# of gel per bbl
must be placed between each plug**

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Sarah Jordan TITLE Production Analyst DATE 11-13-2002

TYPE OR PRINT NAME Sarah Jordan

TELEPHONE NO. 915/686-8235

(This space for State Use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

NOV 18 2002