

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.	27210
30-015-27200	
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	VB-212
7. Lease Name or Unit Agreement Name	Rancherita AHM State Com
8. Well No.	1
9. Pool name or Wildcat	North Hoag Tank Strawn Gas
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	3762' GR

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL WELL ☐ GAS WELL ☒ OTHER

2. Name of Operator  
YATES PETROLEUM CORPORATION

3. Address of Operator  
105 South 4th St., Artesia, NM 88210

4. Well Location  
Unit Letter N : 660 Feet From The South Line and 1980 Feet From The West Line  
Section 8 Township 19S Range 24E NMPM Eddy County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:

1. Set CIBP at 7875' and cap with 35' of cement.
2. GIH w/tubing and load hole from 7840' with plugging mud.
3. TOOH with tubing.
4. Set CIBP at 6180' and cap with 35' of cement.
5. TIH w/tubing.
6. Spot a 25 sack cement plug across top of Abo from 3775'.
7. Spot a 25 sack cement plug across 9-5/8" shoe from 1250'.
8. Spot a 100' cement plug at surface.
9. Cut off wellhead. Install regulation abandonment marker.

RECEIVED

MAR - 9 1995

OIL CON. DIV.  
DIST. 2

NOTIFY OCD - ARTESIA (505-748-1283) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Rusty Klein*

TITLE Production Clerk

DATE 3-8-95

TYPE OR PRINT NAME

Rusty Klein

TELEPHONE NO. 505/748-1471

(This space for State Use)

ORIGINAL SIGNED BY TIM W. GUM  
DISTRICT II SUPERVISOR

APPROVED BY

TITLE

DATE

MAR 30 1995

CONDITIONS OF APPROVAL, IF ANY: