

BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED BY
JUN 18 1984

O. C.
ARTESIA, OFFICE

BUREAU OF LAND MANAGEMENT
RECEIVED
JUN 11 1984
DIST. 6 N.M.
Carlsbad New Mexico

5. LEASE DESIGNATION AND SERIAL NO.

LC-063567

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Yates Federal

9. WELL NO.

12

10. FIELD AND POOL, OR WILDCAT

McMillan 7-Rivers Queen

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec 7, T-20S, R-27E

12. COUNTY OR PARISH

Eddy

13. STATE

N.M.

1. OIL WELL ☐ GAS WELL ☐ OTHER WIW

2. NAME OF OPERATOR

Yates Energy Corporation

3. ADDRESS OF OPERATOR

Sunwest Centre, Suite 919, Roswell, New Mexico 80201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.)

See also space 17 below.)

At surface

330' FNL & 1650' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3367' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FILL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

Revised request for approval to Plug to

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

Abandon

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Copy state all pertinent details, and give pertinent dates, including estimated date of starting and proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

6/11/84 TD 767'; 7" @ 435' w/20 sx cement, water sands 325'-330', water sands 345'-355'. We plan to spot 200' plug 335' to 535', displace with brine water or mud. Feel of plug top, respot if not in place, feel again. Leave brine or mud to surface. Perforate 7" casing at approximately 200' (150' to 250'). Circulate cement. 4" pipe dry hole marker at the surface.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE John R. McMinn, Engineer

DATE June 11, 1984

(This space for Federal or State office use)

APPROVED BY

TITLE P.E.

DATE 6/11/84

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

RECEIVED BY
JUN 13 1984
O. C. D.
ARTESIA, OFFICE

RECEIVED
JUN 14 1984
O.C.D.
HOBBS OFFICE