

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

**OIL CONSERVATION DIVISION**  
**RECEIVED BY**  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501  
**JAN 15 1985**  
**O. C. D.**  
**ARTESIA, OFFICE**

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

**SUNDRY NOTICES AND REPORTS ON WELLS**

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Harvey E. Yates Company	8. Farm or Lease Name Hondo Singer "C"
3. Address of Operator P. O. Box 1933, Roswell, New Mexico 88201	9. Well No. 1
4. Location of Well UNIT LETTER <u>F</u> 1980 FEET FROM THE <u>North</u> LINE AND 1980 FEET FROM THE <u>West</u> LINE, SECTION <u>18</u> TOWNSHIP <u>20S</u> RANGE <u>27E</u> N.M.P.M.	10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 3331' GL	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPMS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

EXISTING: Perfs @ 6463' to 6505' & retainer @ 6731'.

**PROCEDURE:**

1. Dump 35' cmt on top of retainer.
2. Cmt over perfs & up to 50' above. Tag Cmt.
3. Set 100' plug from 5250' - 5350' (Top of Bone Springs)
4. Set 100' plug from 3900' - 4000'
5. Tag cmt. Perf @ 2978' & spot 200' & put 100' into perfs.
6. Set 100' plug @ 2920' - 3920'.
7. Cut off well head equip.
8. Set surface plug w/25 sxs cmt.

APPROVED Mike Williams 1/8/85.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signed Layne Ellis TITLE Regulatory Administrator DATE 1/11/85

APPROVED BY Mike Williams TITLE OIL AND GAS INSPECTOR DATE JAN 17 1985

CONDITIONS OF APPROVAL, IF ANY: