

Copy 2

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

N.M.-01072

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. NAME OF LEASEE
Federal Oil Lease

9. WELL NO.
1-16

10. FIELD AND POOL, OR WILDCAT
Wildcat

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
S.16, T26S, R29E, N4PM

12. COUNTY OR PARISH
Levy

13. STATE
N.H.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. NAME OF OPERATOR
John H. Trigg ✓

3. ADDRESS OF OPERATOR
P. O. Box 106 - Maljamar, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.)
At surface 660 Feet from North Line and 660 Feet from West Line

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☒

ABANDON* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

June 24, 1964 - TD 1379. PSTD 1334' w/Cast Iron Bridge Plug @ 1294'. 4 1/2" casing set @ 1378' w/50 ex. 7" casing set @ 104' w/50 ex. Perf. 1270-74'.

We propose to plug and abandon this well in the following manner;

1. Set 15 sack cement plug from 1134' to 1294'.
2. Fill hole with good mud.
3. Unscrew 4 1/2" casing where it will come loose, should not be below 400', and remove from hole.
4. Set a 10 sack cement surface plug.
5. Erect regulation marker.
6. Clean up location.

Notice will be given when location is ready for final inspection.

RECEIVED

JUN 30 1964

O. C. C.
ARTESIA, OFFICE

18. I hereby certify that the foregoing is true and correct

Production Clerk

June 24, 1964

SIGNED *R. E. Shook*

TITLE

DATE

(This space for Federal or State office use)

APPROVED
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

JUN 29 1964
R. E. Shook
RONNIE E. SHOOK
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

NOV 19 1944
LIBRARY
U. S. DEPARTMENT OF THE ARMY
WASHINGTON, D. C.