

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN THE MANNER INDICATED*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

New Mexico - 02295

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal "TY" Lease

9. WELL NO.

2-3

10. FIELD AND POOL, OR WILDCAT

Undesignated

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

S.3, T20S., R27E.

12. COUNTY OR PARISH

Edley

13. STATE

N. M.

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Dry Hole

2. NAME OF OPERATOR

John M. Trigg

3. ADDRESS OF OPERATOR

P. O. Box 106 - Maljamar, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660 Feet from North Line & 1650 Feet from East Line

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3380.8 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

XXX

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon this well at a total depth of 1397' in the following manner as outlined via telephone conversation with Mr. Knopf on February 23, 1965;

1. Run tubing to total depth and fill hole with heavy mud.
2. Set 35 sack cement plug from 1200' to 1300'.
3. Set 35 sack cement plug from 400' to 500'.
4. Pull 8-5/8" casing that was mudded @ 245'.
5. Set 35 sack cement plug from 200' to 300'.
6. Set 10 sack cement surface plug.
7. Erect regulation marker and clean up location.

Notice will be given when the above is accomplished.

RECEIVED

18. I hereby certify that the foregoing is true and correct

SIGNED

Kenneth E. Aston

TITLE

Production Clerk

DATE

Feb. 24, 1965

(This space for Federal or State office use)

APPROVED BY

Rudolph C. Baird, Jr.

TITLE

ACTING DISTRICT ENGINEER

DATE

FEB 23 1965

CONDITIONS OF APPROVAL, IF ANY:

Oval Approval

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.