

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TR  
(Other instruct.  
verse side)CATE\*  
on re-Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 070286

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		APR 29 1977	
2. NAME OF OPERATOR		Pennzoil Company	
3. ADDRESS OF OPERATOR		P. O. Drawer 1828 - Midland, Texas 79701	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface		838' FNL & 1650' FWL of Sec. 4, T-21-S, R-29-E	
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3425' G.L.	
7. UNIT AGREEMENT NAME		8. FARM OR LEASE NAME Hudson Federal	
9. WELL NO. 1		10. FIELD AND POOL, OR WILDCAT Golden Lane Strawn	
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 4, T-21-S, R-29-E		12. COUNTY OR PARISH Eddy	
13. STATE N. M.			

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

XX

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Plug & abandon non-commercial well with no other productive zones.  
Rig up casing pulling unit 7-9-76

1. Pull tubing & packer
2. Spot 35 sx. cement plug from 11,075-10,760'.
3. Cut & pull 5 1/2" casing @ free point.
4. Spot 50 sx. cement plug @ the top of the 5 1/2" casing stub.
5. Spot 50 sx. cement plug in & out the base of the 8 5/8" casing if the 5 1/2" casing stub is below 4052'.
6. Spot 10 sx. cement plug in surface of 8 5/8" & install marker.
7. Clean & level location.

Hole will be loaded w/9.6#/gal. mud laden fluid.

Verbal approval received July 2, 1976.

RECEIVED

JUL - 7 1976

U. S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

(This space for Federal or State office use)

TITLE Advanced Petroleum Engr.

DATE July 6, 1976

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

\*See Instructions on Reverse Side