

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.
NM 12097

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.
Rocky Arroyo #1

9. API Well No.

10. Field and Pool, or Exploratory Area

11. County or Parish, State
Eddy, N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

RECEIVED

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator
D-M-S Oil Company

3. Address and Telephone No.
3000 Wilcrest, Suite 250 Houston, Texas 77042

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
Sec 8 T - 22 - S R - 22 - E 1980 FSL 1980 FNE

O. C. D. ARTESIA, OFFICE

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Set 5 1/2 CIBP at 6500 Cap W/35' cement perforations at 6563' - 6600'
 - 2) Load hole W/mud
 - 3) Cut and pull 5 1/2 casing at appox. 3300'
 - 4) Spot 100' cement plug at 5 1/2 stub and W.O.C. tag
 - 5) Spot 100' Cement plug at 9 5/8 shoe and W.O.C. tag
 - 6) Spot 100' Cement plug at 13 3/8 shoe
 - 7) Spot 50' Cement plug at Surface
- CAP WOLFAMP FORMATION w/140' cmt plug (4505'-4365').

14. I hereby certify that the foregoing is true and correct

Signed Raymond Maldonado Title Supervisor Date 5-23-94

(This space for Federal or State office use)

Approved by Orig. Signed by A Title Petroleum Engineer Date 5/23/94

Conditions of approval, if any:
ATTACHED